

Hydraulic // 0...1000 bar



P700.3 Basic



P1000.2 Solid

Your advantages

Type	P700.3 / P1000.2
	<ul style="list-style-type: none"> • Testing, adjustment and calibration of all types of pressure gauges • Precise adjustment thanks to ultra-fine thread pitch and large volume control valve • High pressure generation with minimum effort • Large calibration volume (300 ml)

Technical data

Type	P700.3		P1000.2	
Pressure range	0...700 bar		0...1000 bar	
Pressure medium	Demineralized water or hydraulic oil			
Connections				
Reference pressure gauge	G1¼			
Test sample	G1¼ with quick coupling and pressure hose (1 m)		G1¼ with quick coupling and high pressure hose (1 m)	
Basic				
Dimensions	Approx. 255 x 225 x 85 mm			
Weight	Approx. 1,7 kg		Approx. 1,9 kg	
Solid				
Dimensions (case)	Approx. 450 x 370 x 125 mm			
Weight	Approx. 4,8 kg		Approx. 5 kg	
+ Adapter kit	Stainless steel, G½, G¼, G¾, G½, ⅙ NPT, ¼ NPT, ½ NPT, M12 x 1.5, M20 x 1.5, G⅝, G¼			
+ Seal kit	PA flat gaskets and O-rings			

Order code		
Type	Version	Order number
P700.3	Basic	EPPM700EBL0003
	Solid (incl. case and adapter)	EPPM7000BL0003
P1000.2	Basic	EPPM1K0EBL0002
	Solid (incl. case and adapter)	EPPM1K00BL0002

